

[illegible]

System Speed Dial numbers 010–499

11.1 cm

SINGLE LINE TELEPHONES

TO MAKE AN OUTSIDE CALL

- Dial Access Code (0)
- Dial Telephone number

TO ANSWER AN INCOMING CALL

Ringling on your phone :

- Lift the handset

TO TERMINATE A CALL

- Replace the handset

TO CALL THE SWITCHBOARD

- Dial 9

TO CALL AN EXTENSION

- Dial Extension number

TO CALL AN EXTENSION HUNT GROUP

(Programmable)

- Dial 78
- Dial Extension Hunt Group number (1 – 8)

WHO WAS THAT ??

- Dial your own Extension number
- This will ring the Extension that last tried to call you.

VOICE ANNOUNCE/SIGNAL CALLING

When an Intercom Call is made to a Terminal, the caller can switch from Signal Calling (ringing) to Voice Announce :

- Press # (during ringing)

Speed Dial Numbers

[illegible]

Hymax 32

Personal Speed Dial numbers 01 – 09

System Speed Dial numbers 10 – 99

Hymax 32i

Personal Speed Dial numbers 001 – 009

System Speed Dial numbers 010–999

Hymax 128

Personal Speed Dial numbers 001 – 009

System Speed Dial numbers 010 – 499

SLT 2

[illegible]

- Press **'R'** *or* **'Flash'** key

- Press '**R**' *OR* '**Flash**' key again.

- Put a call on Hold
- Call extension
- Announce the call (if not busy) (optional)
- Replace the handset

HOLD PICKUP

- Dial 75
- Dial Extension number

- Put Call on hold
- Dial 76
- Dial Call Park Bin number (0 – 9)
- Press # key

TO RETRIEVE A PARKED CALL

- Dial 76
- Dial Call Park bin number (0 – 9)
- Press # key

CALLBACK WHEN FREE

Automatic Callback by Busy Extension or Line

- Dial Extension or Line access (Busy)
- Dial 7

System will call back when the Extension or Line is available.

The callback will be automatically cancelled within 20 seconds.

TO SET A MESSAGE

- Dial 743
- Dial Extension number

TO CLEAR A MESSAGE

From the Extension that set the Message.

- Dial 740
- Dial Extension number

From the Extension that received the Message.

- Dial 744*

TO RESPOND TO A MESSAGE

- Dial 744

Message waiting is indicated on a Single-Line

Telephone by a message waiting light or a short ring every 10 minutes.

RINGING-CALL PICKUP

“Directed Call Pickup” from an Extension.

- Dial ringing Extension number
- Press * key

“Group Call Pickup” from an Extension Group.

- Dial Extension Group number (1 – 7)
- Press * key

“System Call Pickup” will answer any ringing

Press * key

CALL DEDICATED DOOR PHONE

If your system is equipped with a Dedicated Door Phone, it can be called ;

- Dial 791

The Door Unit can also be used as a room monitor.

To unlock the Door while talking to the Door Unit;

- Dial 0

Features and Dial Codes

<u>Dial</u>	<u>Features</u>
0	Access an Outside Line
77+Line no.	Access a specific Outside Line
71* + EXT + 1	Call Forward – Follow Me ON
71* + EXT + 2	Call Forward –Follow Me Off
71 + EXT.	Call Forward – All Calls
72 + EXT.	Call Forward When Busy
73 + EXT.	Call Forward When No Answer.
78 + (1 – 8)	Call EXT Hunt Group (1-8)
791	Call the Dedicated Door Phone.
76 + (0 – 9)	Call Parking .
9	Call the Switchboard
EXT + *	Call Pickup – Directed (EXT)
1 – 7 + *	Call pickup - Group
*	Call Pickup – System (General).
748	Conference
747	Do-Not-Disturb.
75 + EXT	Hold Pickup.
‘R’ OR ‘FLASH’	Put Call on Hold.
74# + Lock Code	Lock your Phone
749 + Lock Code	Unlock your Phone
741 + HHMM	Meeting Reminder – Daily
742 + HHMM	Meeting Reminder – Once Only.
743 + EXT.	Message – Set.
744	Message – Respond.
744*	Message – Clear.
740 + EXT.	Message – Clear.
1-7 + #	Page a Group of Terminals.
# + (1 – 8)	Page and External Zone(1-8)
# 9	Page All Internal.
# 0	Page All External.
# #	Paging Call Answer
70 #	Redial.
746 + SD number	Program Speed Dial (personal)
70 + (01 – 99)	Speed Dialing H-32
70 + (001 – 999)	Speed Dialing H-32i
70 + (001 – 499)	Speed Dialing H-128
Own EXT.	Call last EXT. (Who Was That?)

SLT 4

PAGE A GROUP OF TERMINALS

- Lift handset
- Dial Extension Group number (1 – 7)
- Press # key
- Pause for tone
- Make your announcement

PAGE ALL TERMINALS

- Lift handset
- Press # key
- Dial 9
- Pause for tone
- Make your announcement

EXTERNAL PAGE

Paging through external speakers

- Lift handset
- Press # key
- Dial Zone Number (1 – 8)
- Pause for tone
- Make your announcement

To page ALL Zones use Zone number 0.

PAGE ALL INTERNAL & EXTERNAL

- Lift handset
- Press # key
- Press * key
- Pause for tone
- Make your announcement

ANSWERING A PAGING CALL

Meet-Me Page

- Lift handset
- Press # key twice

PROGRAM PERSONAL SPEED DIAL

- Dial 746
- Dial Speed Dial Code 01 – 09 for H-32
- Dial Speed Dial Code 001 – 009 for H-32i
- Dial Speed Dial Code 001 – 009 for H-128
- Dial telephone number *or* nothing to clear
- Replace handset

USING SYSTEM / PERSONAL SPEED DIAL

Without seizing an Outside Line:

- Dial 70
- Enter Speed Dial Code 01 – 09 for H-32
- Enter Speed Dial Code 001 – 999 for H-32i
- Enter Speed Dial Code 001 – 499 for H-128

LAST NUMBER REDIAL

Without seizing an Outside Line:

- Dial 70
- Press # key

DO NOT DISTURB

To set or clear Do Not Disturb:

- 747

When the handset is lifted a Special tone will be heard.

SET MEETING REMINDER CALL

Once only Reminder call:

- Dial 742
- Enter Time (HHMM)

Daily Reminder call:

- Dial 741
- Enter Time (HHMM)

For HHMM use 24 Hour format

To cancel Meeting Reminder:

- Dial 741 or 742
- Replace handset

SLT 5

CALL FOLLOW ME

To forward all calls from another Extension :

- Lift the handset
- Dial 71
- Press * key
- Type in your own Extension number
- Dial 1 to activate
- Dial 2 to de-activate

This diverts all calls from your Extension to the Extension doing the setting i.e. that you are sitting at.

CALL FORWARDING – ALL CALLS

To Forward All Calls to another Extension :

- Dial 71
- Dial Extension number that must receive your calls.

To Forward All Calls to an External Number :

- Dial 71
- Press # key
- Enter Speed Dial Code 01 – 09 for H-32
- Enter Speed Dial Code 001 – 999 for H-32i
- Enter Speed Dial Code 001 – 499 for H-128

When the handset is lifted a Special Tone will be heard.

CALL FORWARDING WHEN BUSY

To Forward Calls to another Extension when Busy:

- Dial 72
- Dial Extension number that must receive your calls.

To Forward Calls to an External Number :

- Dial 72
- Press # key
- Enter Speed Dial Code 01 – 09 for H-32
- Enter Speed Dial Code 001 – 999 for H-32i
- Enter Speed Dial Code 001 – 499 for H-128

When the handset is lifted a Special Tone will be heard.

CALL FORWARDING NO ANSWER

To Forward Calls to another Extension when No Answer:

- Dial 73
- Dial Extension number that must receive your calls.

To Forward Calls to an External Number :

- Dial 73
- Press # key
- Enter Speed Dial Code 01 – 09 for H-32
- Enter Speed Dial Code 001 – 999 for H-32i
- Enter Speed Dial Code 001 – 499 for H-128

When the handset is lifted a Special Tone will be heard.

TO CANCEL ALL CALL FORWARDS

- Dial 71, 72 or 73

INTRUDE TONE

- Call Extension (Busy)
- Dial 1
- Wait for Extension to respond

To respond to Intrude Tone:

- Press ‘R’ or ‘Flash’ key

You will be connected to the calling Extension

TO LOCK YOUR PHONE

- Dial 74#
- Dial password code (1 – 6 digits)
- Replace the handset

To Unlock your phone:

- Dial 749
- Dial the same password code (1 – 6 digits)

CONFERENCE

- Make the initial call (Internal or External)
- Press ‘R’ or ‘Flash’ key
- Make the second call (Internal or External)
- Press ‘R’ or ‘Flash’ key
- Dial 748

All three parties will now be connected.

SLT 6