

## Speed Dial Numbers

## Hymax 32

Personal Speed Dial numbers 01 – 09

### ***System Speed Dial numbers 10 – 99***

## Hymax 32i

Personal Speed Dial numbers 001 – 009

**System Speed Dial numbers 010 – 999**

## Hymax 128

### Personal Speed Dial numbers 001 – 009

### ***System Speed Dial numbers 010 – 499***

## **Hymax Service Information**

When you require service from any **Hymax** Service Centre, please ensure that you supply as much information as possible along with your query or request.

If you provide accurate details about a problem, this will enable the **Hymax** Service Centre to rectify the problem in the shortest time possible. With your assistance, problems can often be rectified over the telephone in an even shorter time.

Certain **Hymax** Service Centres may require a faxed request for service. Faxing is a convenient way of requesting help if you provide full details of your request as the information is accurate and guaranteed to go to the correct person.

# Hymax 32 Switchboard User Guide

If the service call is chargeable then an official order is required. This order can be faxed along with details of the required service.

## ***Hymax Service Contact Information***


The **Hymax** Service Centres pride themselves on providing the kind of service you expect, but rarely get.

SWB 1

6.4 cm

6.8 cm Times Roman 24

7.8 Size H=.92 W=3.15 Times R 30  
Scale 92% 94%  
8.7 cm Arial 16  
9.4 cm

10.1 cm Times Roman 12  
10.6 cm Times Roman 12  
11.1 cm

## Speed Dial Numbers

## Hymax 32

Personal Speed Dial numbers 01 – 09

### *System Speed Dial numbers 10 – 99*

## Hymax 32i

### Personal Speed Dial numbers 001 – 009

*System Speed Dial numbers 010 – 999*

## Hymax 128

### Personal Speed Dial numbers 001 – 009

*System Speed Dial numbers 010 – 499*

## **Hymax Service Information**

When you require service from any **Hymax** Service Centre, please ensure that you supply as much information as possible along with your query or request.

If you provide accurate details about a problem, this will enable the **Hymax** Service Centre to rectify the problem in the shortest time possible. With your assistance, problems can often be rectified over the telephone in an even shorter time.

Certain **Hymax** Service Centres may require a faxed request for service. Faxing is a convenient way of requesting help if you provide full details of your request as the information is accurate and guaranteed to go to the correct person.

TERM 1

# **Hymax 32**

## Terminal User Guide

If the service call is chargeable then an official order is required. This order can be faxed along with details of the required service.

## ***Hymax Service Contact Information***


The **Hymax** Service Centres pride themselves on providing the kind of service you expect, but rarely get.

## SWITCHBOARD FEATURES

*Switchboard features can only be used at a Terminal that has been set as a Switchboard.*

## ASSIGN ALTERNATE OPERATOR

- Press **PROG** key
- Press # key
- Dial Extension number

## DAY / NIGHT SERVICE

- Press **PROG** Key
- Press **TRF** key

*To switch between Day and Night Mode:*

- Press **TRF** key again

\*\*

*To exit:*

- Press **RLS** key

*The DND lamp is on solid when the system is in Night Mode.*

**\*\*To switch between Automatic and Manual Mode**

- Press **FLASH**

*To set Day and Night Mode transfer times:*

- Enter Day Mode start time (HHMM)
- Enter Night Mode start time (HHMM)

## SET EXTENSION MEETING REMINDER CALLS

- Press **PROG** key
- Press **CAMP** key
- Dial Extension number
- Enter Time (HHMM)
- (Press **FLASH** key to cancel)
- Press **RLS**

## Speed Dial Numbers

## Hymax 32

### Personal Speed Dial numbers 01 – 09

### *System Speed Dial numbers 10 – 99*

## Hymax 32i

### Personal Speed Dial numbers 001 – 009

*System Speed Dial numbers 010 – 999*

## Hymax 128

### *Personal Speed Dial numbers 001 – 009*

*System Speed Dial numbers* 010 – 499

SWB 2

## NOTES:

## PROGRAM SYSTEM SPEED DIAL

SWB 3

- Press **PROG** key twice
- Enter **PASSWORD**
- Press **HOLD**
- Press **SPEED** key
- Dial Speed Dial Code 10 - 99 for H-32  
Dial Speed Dial Code 010 - 999 for H-32i  
Dial Speed Dial Code 010 - 499 for H-128
- Enter Telephone number

Press **FLASH** key to clear a number

- Press **HOLD** key to save

*To insert a pause in the number sequence press **CAMP** key. To insert a flash in the number sequence press **CONF** key. To switch between Pulse and DTMF dialing press **PROG** key.*

*Speed Dial numbers over the preset threshold number can override Toll Restriction.*

To look at the programmed Speed Numbers use **MIC** to go down the list and **TRF** to go up the list.

## **TO PROGRAM AUTO REDIAL**

- Press **PROG** key
- Press **REDIAL** key
- Enter number of attempts
- Press **HOLD** key
- Enter number of seconds to ring
- Press **HOLD** key
- Enter number of seconds between attempts
- Press **HOLD** key

Press **FLASH** key to clear any item

## **TO LOCK and UNLOCK A PHONE**

- Press **PROG** key
- Press **0**
- Press **PROG** key
- Enter Extension number
- Press **MSG** key to Lock
- Press **FLASH** key to Unlock
- Press **HOLD** key to save

## **HANDS FREE OPERATION**

All Terminals can operate handsfree.

*For handsfree operation, the Speaker and Microphone will automatically turn on, when you press the **MIC** key, if the handset has not been lifted. To activate handsfree operation during a call, press the **MIC** key and replace the handset.*

*To end handsfree operation simply lift the handset and continue the conversation or press **RLS** to terminate the call.*

*Handsfree operation is not available for Paging and Intrude (Outside Line or Extension).*

*To turn the microphone on and off during handsfree mode, press the **MIC** key*

## AUTOMATIC TRUNK SELECTION

*If an Outside Line has not already been accessed for Redial and Speed Dial, the system will access an Outside Line automatically.*

## DSS or DIRECT STATION SELECTION

*The DSS is the panel on the Terminal which has 24 Keys that can be programmed for Exchange Lines, Extensions or Speed Dial numbers.*

## WARNING TONE

*When activated, a tone will be received at programmed intervals while talking on an Outside Line to remind caller of call length.*

## Speed Dial Numbers

Hymax 32

### Personal Speed Dial numbers 01 – 09

### *System Speed Dial numbers 10 - 99*

## **Hymax 32i**

### Personal Speed Dial numbers 001 – 009

*System Speed Dial numbers 010 – 999*

## **Hymax 128**

*Personal Speed Dial numbers 001 – 009*

**System Speed Dial numbers** 010 – 499

SWB 4

TERM 2

## TERMINAL KEY FUNCTIONS

### **DATA / DND**

Do Not Disturb. Night Mode light (indicator)

### **SPEED / INT**

Speed Call Numbers. Internal Call light.

### **CONF**

Used to set up 3 and 7 way Conference.  
Intrude.

### **PROG**

Used for Programming

### **CAMP**

Intrude Tone

### **MSG**

Set and Respond to Message Calls. Outside Line  
Volume control.

### **REDIAL / CB**

Last Number Redial. Call Back When Free.

### **FLASH**

To clear Data in Programming Mode.

To clear same line for re-use.

### **HOLD**

Put calls on Hold and Retrieve Calls from Hold.  
Save Program Settings.

### **MIC**

Allows Handsfree Mode. Handsfree Mute.

### **TRF**

Transfer Calls. Night & Day Mode Toggle.

### **RLS**

Release or Terminate a Call.

## **TERMINAL FEATURES**

### **SWB 5**

TERM 3

### **TO MAKE AN OUTSIDE CALL**

- Dial Access Code
- Dial Telephone number

### **TO ANSWER AN INCOMING CALL**

*Ringing on your phone:*

- Lift handset

### **TO TERMINATE A CALL**

- Press **RLS** key

*Or*

- Replace handset

### **TO CALL AN EXTENSION**

- Dial Extension number

*Or*

- Press a **DSS** key

### **TO CALL THE SWITCHBOARD**

- Dial 9

### **TO CALL AN EXTENSION HUNT GROUP**

*(Programmable)*

- Dial 78
- Dial Extension Hunt Group number (1 - 8)

### **TO PUT A CALL ON HOLD**

- Press **HOLD** key

*To retrieve the call:*

- Press **HOLD** key or flashing **DSS** key

The **HOLD** key functions as 'Last In First Out'

## TO TRANSFER A CALL

- Press **DSS** key (HOLD is automatic)
- Announce the call (if not busy) (optional)
- Press **TRF** key

OR

- Press **HOLD** key
- Dial Extension number
- Announce the call (if not busy) (optional)
- Press **TRF** key

*When transferring a call to a busy Extension, the call will be camped on. When the Extension replaces the handset, the phone will ring.*

## HOLD PICKUP

*To retrieve the last call put on hold by another Extension.*

- Dial 75
- Press **TRF** key

## EXCLUSIVE HOLD

*This prevents other Extensions retrieving the call.*

- Press **HOLD**
- Press **TRF** key

## TO PARK A CALL

- Press **HOLD** key
- Dial 76
- Dial Call Park bin number (0 - 9)
- Press **TRF** key

*If Park bin is occupied (indicated by a Special Tone) dial another Call Park bin number.*

## TO RETRIEVE A PARKED CALL

- Dial 76
- Dial Call Park bin number (0 - 9)
- Press \* key

## SET TERMINAL DISPLAY MESSAGES

*Messages:*

1. Call (4329988)
2. Call St: (24)
3. Meeting (5:30)
4. Be Back (4:30 or 7/19)
5. Day Off (7/30)
6. Lunch (12:00)
7. Vacation (7/23)
8. Off Duty (5:00)
9. (Personal Message)

*To set:*

- Press **PROG** key
- Press **MSG** key
- Dial Message number (1 – 9)

Press **FLASH** key to cancel

- Enter Date/Time (\* for “.”, # for “I”)
- Press **RLS** key

For the personal message:-

Press 2 once for “a”, twice for “b”, three times for “c”. Press 1 for “q” and “z”. The “0” key does the full alphabet and also all symbols. The \* key moves one space to the left and the # key one space to the right.

## CALL DEDICATED DOOR PHONE

*If your system is equipped with a Dedicated Door Phone (Hymax 32 Only), it can be called;*

- Dial 791

*The Door Unit can also be used as a room monitor.*

*To unlock the Door while talking to the Door Unit;*

- Dial 0

## SWB 6

## TERM 4

## PAGE A GROUP OF TERMINALS

- Lift handset
- Dial Extension Group number (1 – 7)
- Press # key
- Pause for tone
- Make your announcement

## PAGE ALL TERMINALS

- Lift handset
- Press # key
- Dial 9
- Pause for tone
- Make your announcement

## EXTERNAL PAGE

*Paging through external speakers*

- Lift handset
- Press # key
- Dial Zone Number (1 – 8)
- Pause for tone
- Make your announcement

*To page ALL Zones use Zone number 0.*

## PAGE ALL INTERNAL & EXTERNAL

- Lift handset
- Press # key
- Press \* key
- Pause for tone
- Make your announcement

## ANSWERING A PAGING CALL

*Meet-Me Page*

- Lift handset
- Press # key twice

## CALL BACK WHEN FREE

*Automatic Callback by busy Extension or Line*

- Dial Extension or Access Line (Busy)
- Press **REDIAL/CB** key

*System will call back when Extension or Line is available.*

*The call back will be automatically cancelled if not answered within 20 seconds.*

## TO SET A MESSAGE

- Call Extension
- Press **MSG** key

*The MSG lamp on a Terminal will flash when there is a waiting message.*

## TO RESPOND TO A MESSAGE

- Press **MSG** key

## TO CLEAR A MESSAGE

*Only by the Extension that set the Message.*

- Call Extension
- Press **FLASH** key

## RINGING CALL PICKUP

“Directed Call Pickup” from an Extension;

- Call Ringing Extension
- Press \* key

“Group Call Pickup” from an Extension Group;

- Dial Extension Group number (1 – 7)
- Press \*

“System Call Pickup” will answer any ringing call;

- Press \* key

## SWB 7

## TERM 5

## PROGRAM PERSONAL SPEED DIAL

- Press **PROG** key
- Press **SPEED** key
- Dial Speed Dial Code 01 – 09 for H-32
- Dial Speed Dial Code 001 – 009 for H-32i
- Dial Speed Dial Code 001 – 009 for H-128
- Dial number or **FLASH** to clear
- Press **HOLD** key

*To insert a pause in the number sequence press **CAMP** key. To switch between Pulse and DTMF dialing press **PROG** key.*

## USING SYSTEM / PERSONAL SPEED DIAL

*Without seizing an Outside Line:*

- Press **SPEED** key
- Enter Speed Dial Code 01 – 09 for H-32
- Enter Speed Dial Code 001 – 999 for H-32i
- Enter Speed Dial Code 001 – 499 for H-128

## LAST NUMBER REDIAL

*Without seizing an Outside Line:*

- Press **REDIAL** key

## SAVED NUMBER REDIAL

*To save the number already dialed, while on an Outside Line:*

- Press **SPEED** key
- Press \* key

*To call the number again:*

- Press **SPEED** key
- Press # key

## ON-LINE SAVED NUMBER

*To save a number while on an Outside Line:*

- Press **DATA** key during conversation
- Enter number to be saved

*To call the number again:*

- Press **SPEED** key
- Press **DATA** key

## DO NOT DISTURB

*To set or clear:*

- Press **PROG** key
- Press **DATA** key

*The Do Not Disturb lamp flashes when set.*

## SWB 8

## TERM 6

## INTRUDE ON AN OUTSIDE CALL

*(Only if Programmed for this function)*

- Lift handset
- Call Extension
- Receive Busy Tone
- Press **CONF** key
- You can now converse with the Extension

## EXECUTIVE MONITORING

*(Only if Programmed for this function)*

- **DO NOT** Lift the handset
- Access an Outside Line or Call Extension
- Receive Busy Tone
- Press **CONF** key
- You are now monitoring the call

*If handset is lifted, Intrude feature will be in effect.*

## WHO WAS THAT ??

- Dial Your Own Extension Number
- This will ring the extension that last tried to ring you.

## SMDR ACCOUNT CODE

*To enter an account code while on an outside call.*

*Account code may include 0 – 9, \*, #.*

- Press **MSG** key
- Dial account code (up to 8 digits long)

## AUTO REDIAL

(Programmable)

- Do **NOT** lift handset
- Make an Outside Call (number is busy)
- Press **REDIAL** key
- System will automatically redial up to 99 times
- Lift handset when ringing is heard.

*To re-activate, press **REDIAL** twice without lifting the handset.*

*If Auto Redial has not been programmed, the system will Redial only once.*

## SET MEETING REMINDER CALL

*Once only Reminder call:*

- Dial 742
- Enter Time (HHMM)

*Daily Reminder call:*

- Dial 741
- Enter Time (HHMM)

**For HHMM use 24 Hour format.**

*To cancel:*

- Dial 741 or 742
- Press **FLASH** key

## OUTSIDE LINE VOLUME CONTROL

*To increase handset volume while on an Outside Line.*

- Press **MSG** key
- Press **MSG** key again

*There are two volume levels and the volume is reset to normal when the call is terminated.*

## CONFERENCE (3 Party)

- Make initial call (internal or external)
- Press **HOLD** key
- Make second call (internal or external)
- Press **CONF** key

## SWB 9

## TERM 7

## PRIVACY RELEASE – 7 Party

- Make initial call (internal or external)
- Press **CONF** key

*The next Extension calling your Extension will join the conference.*

*Press **CONF** key again for each additional Extension.*

## INTRUDE TONE

- Call Extension (Busy)
- Press **CAMP** key
- Wait for Extension to respond

*To respond to the Intrude Tone*

- Press **HOLD** key
- You will be connected to the calling Extension

## LOCK YOUR PHONE

- Dial 74#
- Dial password code (1 – 6 digits)
- Press **HOLD** key

*To unlock your phone:*

- Dial 749
- Dial password code (1 – 6 digits)
- Press **HOLD** key

## CALL FOLLOW ME

*To forward all calls from another Extension :*

- Lift the handset
- Dial 71
- Press \* key
- Type in your own Extension number
- Dial 1 to activate
- Dial 2 to de-activate

*This diverts all calls from your Extension to the Extension doing the setting i.e. that you are sitting at.*

## CALL FORWARDING – ALL CALLS

*To Forward All Calls to another Extension :*

- Dial 71
- Dial Extension number that must receive your calls.

*To Forward All Calls to an External Number :*

- Dial 71
- Press # key
- Enter Speed Dial Code 01 – 99 for H-32
- Enter Speed Dial Code 001 – 999 for H-32i
- Enter Speed Dial Code 001 – 499 for H-128

*When the handset is lifted a Special Tone will be heard.*

## CALL FORWARDING WHEN BUSY

*To Forward Calls to another Extension when Busy:*

- Dial 72
- Dial Extension number that must receive your calls.

*To Forward Calls to an External Number :*

- Dial 72
- Press # key
- Enter Speed Dial Code 01 – 99 for H-32
- Enter Speed Dial Code 001 – 999 for H-32i
- Enter Speed Dial Code 001 – 499 for H-128

*When the handset is lifted a Special Tone will be heard.*

## CALL FORWARDING NO ANSWER

*To Forward Calls to another Extension when No Answer:*

- Dial 73
- Dial Extension number that must receive your calls.

*To Forward Calls to an External Number :*

- Dial 73
- Press # key
- Enter Speed Dial Code 01 – 99 for H-32
- Enter Speed Dial Code 001 – 999 for H-32i
- Enter Speed Dial Code 001 – 499 for H-128

*When the handset is lifted a Special Tone will be heard.*

## SWB 10

## TERM 8

## TO CANCEL ALL CALL FORWARDS

- Dial 71, 72 or 73

## VOICE ANNOUNCE / SIGNAL CALLING

When an Intercom Call is made to a Terminal, the caller can switch from Signal Calling to Voice Announce:

- Press # key

## MICROPHONE DEFAULT

*To set your Terminal for automatic Microphone off when receiving a Voice Announce Call;*

- Press **PROG** key
- Press **MIC** key
- Press **FLASH** key to set default to OFF or
- Press **MSG** key to set default to ON.

## BACKGROUND MUSIC

*To play or cancel background music-on-hold:*

- Leave handset down
- Press # key